

# Remote Transponder

Autogate Encryption

Model:UR-43K



JUTAI remote control is one of the automatic sensor door opening systems, it is based on the wireless transmission encryption solution of the extended application solution


How to make the whole system work (Entry auto opening)

- 1.Firstly, save the USB ID number into the receiver (The password should be same)
- 2.Receiver connect to gate controller, when the receiver gets the signal from the USB transponder, the receiver will judging the ID is available.
- 3.If the ID number received by the receiver is valid, the receiver output relay signal and open the door.
- 4.When the car enters the door and leaves the safety range of the coil induction, the door will be closed automatically.

## Technology Parameter

Working voltage	10-30VDC
Frequency	433MHz
Power supply	Powering up remote communication in the car cigarette lighter socket
Remote communication	Copy prevention
Working distance	≤30m
Add or delete card mode	By short connection or special remote control
Encryption method	Encryption with special USB cable

## Gate Automation Application



## Size(mm)

